



Software Applications

UNCERTAINTYPLUS™ Installation Manual

Abstract

This document is the Installation Guide for KELTON™ UNCERTAINTYPLUS desktop application

Contents

Abstract.....	1
1.0 Revision Control.....	3
2.0 Introduction	3
3.0 UNCERTAINTYPLUS Installation	3

1.0 Revision Control

Rev	Issue date	Description	Prep.	App.
1	01/02/17	Format Updated	MH	JON
1.1	28/11/17	Reformatted	KW	JON
1.2	23/07/18	Updated branding applied	WM	JS

2.0 Introduction

Scope

This document outlines the steps required to install the following KELTON software application: UNCERTAINTYPLUS V1.7.x (or higher)

Hardware Specification

The minimum recommended specification a personal computer (PC) for installing the software application is:

- Processor: Core i3 (or higher)
- Memory RAM: 4 GB
- Hard Drive space: 50 GB

3.0 UNCERTAINTYPLUS Installation

Download Applications


The latest version of UNCERTAINTYPLUS can be downloaded as a zip archive file from:

<http://www.kelton.co.uk/Software-Downloads>

Before the application can be installed, extract the contents of the downloaded file. The installation will not be successful if run from within the zip file.


Run Setup

The file Setup.exe should be run as an Administrator with “Elevated Privileges” by right-clicking and selecting the “Run as Administrator” option as shown below.



Installation

Run through the installation accepting all the defaults and the following will be displayed to confirm successful installation.




Licence Management

The first time UNCERTAINTYPLUS is run a message in the title bar will state you do not have a valid licence and the Licence Manager button will be displayed as shown below.



Use the Licence Request button on Licence Management utility to generate a licence request file and send it to support@kelton.co.uk.



When sending the licence request file to KELTON include your license or order number.

Once the request file has been received you will receive a license file UNCERTAINTYPLUS.lic which can be imported using the import button.

If this import process does not work, due to your security settings, manually copy the licence file into: C:\ProgramData\Kelton Engineering Ltd\UNCERTAINTYPLUS

Should you require any further assistance please contact support@kelton.co.uk.